

Embroidered Piping

Instructions for Bernina 1630

gina Butler©2002
Oklahoma City, OK

1. Attach Coded Foot

12C Bulky Overlock or 20C Open Embroidery or 3C Manual Buttonhole

gbokc@cox.net



- ### 2. Select ZZ – Change needle position second right from center. Change Width to apx. 7mm / Length to apx. .5mm (Wide Satin Stitch)



- ### 3. Select SS – Change needle position to full left. Change Width to 0 / leave length at default 2.5mm.



- ### 4. Open MR and select ZZ X 4 / then select SS once.



- ### 5. Sew over purchased piping OR cover piping with metallic lame' before sewing.



- ### 6. Insert in seams as normal piping.

